


## ALCOR USER MANUAL





- I. The luminaire shall be installed by a qualified electrician and wired in accordance with the latess IEE electrical regulations or the national requirements.
- 2. No supplied water-proof box, installation should be adviced by qualified professional.
- 3. The external flexible cable can not be replaced. If the cable is damaged, the luminaire should be discarded.





